

## INSTRUCTION SHEET FOR TOOL NO.2388

## TOOL DRIVER SPACER USE WITH DRIVER TOOLS NO. 33071-73, 94547-80A, 94547-80B USE WITH JIMS® TOOL HANDLE NO. 33416-80





- 1. Refer to H-D Service Manual for specifications.
- 2. Place half of tool into bearing race one at a time.
- With both halves inserted into the bearing race, install tool driver spacer in between halves of tool.
- 4. Install JIMS No. 33416-80 handle into the hole in driver spacer, press out the race.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224

No.2388-IS



REV A 11-13

## INSTRUCTION SHEET FOR TOOL NO.2388

## TOOL DRIVER SPACER USE WITH DRIVER TOOLS NO. 33071-73, 94547-80A, 94547-80B USE WITH JIMS® TOOL HANDLE NO. 33416-80





- 1. Refer to H-D Service Manual for specifications.
- 2. Place half of tool into bearing race one at a time.
- 3. With both halves inserted into the bearing race, install tool driver spacer in between halves of tool.
- 4. Install JIMS No. 33416-80 handle into the hole in driver spacer, press out the race.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.