

Arlen Ness Deep Cut Comfort Grips

Part # Varies by kit **Fits:** 1976-UP HD® Models including 08-UP FLT



Thank you for purchasing this Arlen Ness product. We believe that our products are the very best available and are engineered to provide a lifetime of use. Basic hand tools and an OEM service manual for your year and model motorcycle are all that is necessary to complete this installation.

CAUTION: Use the extreme care using the glue included with this kit. DO NOT get glue on your skin or your eyes. See all warning on the glue.

1. Replace right hand grip per the service manual for your year and model of bike.
2. Using a sharp utility knife, cut off left hand grip.
3. Clean the exposed left side handlebar using sandpaper to achieve a clean surface to attach the new grip to.
4. Prior to installing left side grip, cover any surface that glue could drip on with a towel. At this time also note the angle of the right side grip to ensure that the left grip will be clocked at the same position when installed.

IMPORTANT:

You have one opportunity to install the left side grip properly. Once you stop moving the grip into position the glue used will setup instantly, locking the grip into the place you left it at.

5. Apply glue to the inside of the grip and in one swift movement slide the grip onto the handlebar at the correct position.
6. Wipe off any excess glue in between the grip and the switch housing.