



## Custom Dynamics® Low Rider S Headlamp Mounting Bracket Installation Instructions

We thank you for purchasing the Custom Dynamics® Low Rider S Headlamp Mounting Bracket. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** CD-FXLRS-MOUNT

**Package Contents:**

-Headlamp Mounting Bracket (1)

**Fits:** 2018-2024 Harley-Davidson® Low Rider S (FXLRS). Compatible with 2001-2599 5.75" headlight bucket (sold separately)



### ATTENTION

Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

#### Installation:

1. Refer to the factory service manual and remove the OEM headlight and headlight mount from the lower triple tree.
2. Using the two existing OEM mounting bolts, mount the new FXLRS-MOUNT to the lower triple tree.
3. Install headlight bucket to the mount. Refer to the instructions with the headlight bucket.