



Custom Dynamics® Smoked Tombstone Replacement Lens Installation Instructions

We thank you for purchasing the Custom Dynamics® Smoked Tombstone Replacement Lens. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support. If you have questions before or during installation of this product, please call Custom Dynamics® at 1(800) 382-1388.

Part Number: GEN-TOMB-S

Package Contents:

- GEN-TOMB-S (1)

Fits: 1997-2003 Softail Heritage Springer/Classic, 2005-2017 Softail Deluxe and Softail Deluxe CVO™

Installation:

1. Remove old lens using a Phillips head screwdriver.
2. Locate the three Phillips head screws on the lens.
3. Remove one screw at a time. Hold the lens as you remove screws (keep screws you will need them to reinstall new lens).
4. Clean any dirt or debris from taillight housing.
5. Install lens on housing making sure to line up screws holes (hold lens in place). Using the three Phillips head screws you removed early, install one screw at a time. Do not over tighten screws this could cause the lens to crack.



Safety First: Make sure the bike is parked on a level surface and bike's mechanical components are cool to the touch.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST