



Custom Dynamics® Run/Turn Signal Front Accessory Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Run/Turn Signal Front Accessory Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: MPR-MICRO2-HD

Package Contents:

- Run/Turn Signal Front Accessory Adapter (1)
- Instructions (1)

Fits: 1996-2017 Harley-Davidson® Softails® (except Breakout®, CVO™ Breakout/Pro Street, Rocker/Rocker C, Slim/Slim-S®, Blackline® or Softail® Convertible CVO™), 1997-2011 Dyna Models, 1999-2003 Sportster Models, 1997-2013 Harley-Davidson® Electra Glide, Ultra Classic, Ultra Limited models (including CVO™), Road King (FLHR), Road King Classic (FLHRC), Road Glide Ultra (FLTRU), Road Glide Ultra CVO™ (FLTRUSE), 1998-2009 Road Glide Standard (FLTR), 2006-2009 Street Glide (FLHX), 2010-2011 Street Glide Trike (FLHXXX) and 2010-2013 Tri Glide® Ultra Classic (FLHTCUTG).

Note: Plug and play wire harness connects to OEM wiring to access run power, turn signal power, and ground. Provides left and right side connection points for Custom Dynamics plug and play lighting products such as Micro Turn Signals, Mirror Mount Turn Signals, or LED Mirrors (sold separately).



Installation:

1. Secure motorcycle on level surface. Remove seat and disconnect negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector to the rear fender.
3. Plug the provided Run/Turn Signal Front Accessory Adapter, in-line, into the rear lighting harness and into the bike's main wiring harness.

Note: The order of installation, front to back, will be motorcycles HD main wiring harness, Smart Signal Stabilizer™/Load Equalizer (if installed), Run/Turn Signal Front Accessory Adapter, brake strobe module (if installed), Run/Brake/Turn module (if installed) and then the motorcycles rear lighting harness.

4. Connect any Custom Dynamics® plug and play lighting products such as Micro Turn Signals, Mirror Mounted Turn Signals, or LED Mirrors (Sold Separately) to the installed Run/Turn Signal Front Accessory Adapter.
5. Connect Left Turn Signal to the 4 pin connector of the Adapter with the Violet wire. Connect Right Turn Signal to the 4 pin connector of the Adapter with the Brown wire.
6. Secure wires to prevent the wires from becoming cut, frayed, or pinched.
7. Reconnect the negative battery cable to the battery and reinstall the seat.
8. Test operation of all lighting.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST