



## Custom Dynamics® Run/Turn Signal Front Accessory Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Run/Turn Signal front Accessory Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** MPR-MICROAW-DYN

### Package Contents:

- Run/Turn Signal Front Accessory Adapter (2)
- Instructions (1)

**Fits:** 2012-2017 Harley-Davidson® Dyna Models

**Note:** Plug and play wire harness connects to OEM wiring to access run power, turn signal power, and ground. Provides left and right side connection points for Custom Dynamics® plug and play lighting products such as Micro Turn Signals, Mirror Mount Turn Signals, or LED Mirrors (sold separately).



### **Installation:**

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Locate and remove the left and right frame grommet from the backbone of the frame, just behind the neck.
3. Carefully pull the motorcycles wiring harnesses out of the frame grommet holes and locate the front turn signal connectors on the main wiring harness. The motorcycles wiring harnesses runs through the backbone of the frame, from under the seat area and out the frame grommet holes. It may be necessary to feed the motorcycles wiring harness from under the seat while carefully pulling the wiring harnesses out of the frame grommet holes.
4. Disconnect the front turn signal lighting harnesses from the main harness. Connect one of the Run/Turn Signal Front Accessory Adapter harnesses in-line with the motorcycles front RIGHT turn signal lighting harness and the main harness. Connect one of the Run/Turn Signal Front Accessory Adapter harnesses in-line with the motorcycles front LEFT turn signal lighting harness and the main harness.
5. Connect any Custom Dynamics® lighting products such as Micro Turn Signals, Mirror Mount Turn Signals, or LED Mirrors (Sold Separately) to the installed Run/Turn Signal Front Accessory Adapters.
6. Carefully pull the motorcycles wiring harness back into the backbone of the frame and reinstall the frame grommets.
7. Secure wires to prevent the wires from becoming cut, frayed, or pinched.
8. Reconnect the negative battery cable to the battery and reinstall the seat.
9. Test operation of all lighting.



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**Important:** This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Email: [info@CustomDynamics.com](mailto:info@CustomDynamics.com) or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST