

Installation Instructions

CE-208

The CE-208 will fit 1994 to 2005 all Sportster models.

Regulator-Remove Old Regulator

- 1) Starting from the regulator, follow the wires to the plugs. Disconnect both plugs.
- 2) Unbolt the regulator and remove it.

Install New Regulator

- 1) Mount new regulator. Use the stock mounting bolts with the star washers supplied. Insert star washers between the bolt head and the regulator. This will insure the regulator has a good ground connection.
- 2) Connect stator and battery plugs.
- 5) Start motor and Test battery voltage. Voltage at the battery should run between 14.2 and 14.6.

Have A Good Ride!!

-

For complete product listing and technical information see our web site.

-

WWW.CYCLEELECTRICINC.COM

-