



## HIGH CALIBER FLEXIBLE ANTENNA

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit [Ciro3d.com](http://Ciro3d.com) for our complete warranty policy.

### Included Items:

- Antenna
- M6 x 1.0 - 30mm screw



### Installation Instructions:

1. Park on a level surface and shut off motorcycle. Ensure that the engine has time to cool before installation.
2. If applicable, loosen the set screw near the base of the OEM antenna. Some OEM antennas do not have the set screw.
3. Use a pliers down near the base of the OEM antenna and turn counterclockwise to remove it from the motorcycle.

**NOTE:** Place a shop rag in between the jaws of the pliers to protect the surface.

4. Place a drop of thread locker on the threads of the mount stud. Thread the Ciro antenna onto the motorcycle until tight. (Fig. 1)
5. You may use a pliers down near the base of the Ciro antenna and turn clockwise to tighten. Do not over tighten, just a little torque is all it needs. See note above.

For installation on Indian motorcycles:

Lift boot at base of OEM antenna and unscrew antenna with a wrench turning counterclockwise. Place a drop of thread locker onto supplied M6 x 1.0-30mm screw and thread into the Ciro antenna. Use the OEM lock washer and screw antenna onto base. (Fig. 2)



**NOTE:** Like with most short replacement antennas, you might lose some radio reception. This varies by motorcycle and depends on the area that you live and ride in.