



M8 SOFTAIL PASSENGER FOOTPEG MOUNTING KIT

INSTRUCTIONS

(Please read entire sheet before beginning install)

Parts included:

- 2 - Passenger Footpeg Mounting Brackets
- 2 - $\frac{3}{8}$ -16 x 2 $\frac{3}{4}$ " Alloy SHCS
- 2- Sets of footpeg mounting hardware

Installation Steps:

1. Starting on the right side, remove the factory plastic plugs in the frame where the passenger footpeg is to be installed. Most of the time, the threads behind these plastic plugs will need to be cleaned out (they are usually rusty from the factory). If you use WD-40 or something similar, make sure to remove all the residue prior to installation, so that the threadlocker will be effective.
2. Put one of the supplied bolts through one of the Mounting Brackets, apply medium/blue threadlocker onto the bolt threads, then tighten the bracket into position. When tightening be sure to orient the bracket so that the footpeg will fold up in the clevis at your desired angle. Tighten to 40 ft/lbs.
3. Repeat this process on the left side of the bike.
4. These Mounting Brackets utilize the more common (standard) footpeg clevis. Install your pegs of choice, then GO FOR A RIDE!

General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- On some bikes the threads into the frame may need to be cleaned prior to installation. They have a tendency to develop rust/corrosion.
- Use blue (medium) threadlocker on all threads.

www.DKCustomProducts.com