



M8 Softail E-Z Mount Axle License Plate Bracket

Made in The USA
DK Custom Products

(Please read all instructions before beginning install)

Parts included:

- 1- E-Z Mount License Plate Bracket
- 4- 1/4-20 nut/lock washer sets
- 8- 1/4" Flat washers
- 4- 1/4-20 x 3/8" Button head cap screws

Instructions:

1. This E-Z Mount License Plate Bracket is specifically designed to mount between the axle & the swingarm, in the recessed area on the left side of the swingarm of Milwaukee-Eight Softail Models.
2. The preferred method of installation is to get the bike standing straight up, with very little weight on the rear tire.
3. Loosen the rear wheel axle nut on the right side of the bike. The most you should need to back it off is 1", many times as little as 1/2" is enough. Push the axle toward the left, leaving some space between the head of the axle and the swingarm on the left side. Sometimes the use of a rubber mallet makes it easier to move the axle.
4. Slide the New License Plate Bracket into the recessed area of the swingarm, behind the axle head. It is machined to the contour of the swingarm & will only fit one way. Once it is in place, tighten the axle nut on the right side, pulling the axle head against the new bracket and the swingarm. Tighten the nut to the factory torque settings.
5. Attach your license plate to your new mount, using the hardware we provided, or other hardware of your choice. You may also choose to use a license plate frame.

Note: Should you desire to use a frame, you do Not need to get a curved frame. We have found that a flat frame can easily be tightened down to follow the curve of the License Plate Mount.

6. Go for a ride!

Important Notes:

- The riders safety and product warranty depends on the correct installation of this bracket. Please do not attempt if you have any doubts of your ability to install.
- **We STRONGLY recommend using blue (medium) thread locker on all threads.**

www.DKCustomProducts.com