



## GRAND PRIX STREET SLIP-ON PART # 14-1004 INSTALLATION INSTRUCTIONS

Congratulations, your husband has purchased the finest exhaust system for his, or your, motorcycle. If he's like most guys we are assuming he hasn't read these instructions, which is where you come in. Keep a careful eye on him and when he says he's stuck hand him this Instruction sheet, we included it for a reason. Now for the good news, you picked a great product to enhance the riding experience. Expertly crafted and designed for maximum performance, deep throaty sound, perfect fit and innovative styling. Firebrand exhaust systems are the first choice for people whose passion is riding. Please follow the installation instructions below and if you have any questions, please call our technical support line Toll Free at 844-FIREONE (347-3663). Attention installer (if other than owner), please forward this instruction sheet to the owner of this product. These instructions contain valuable information to the end user.

1. Loosen, but do not remove, the heat shield ahead of the OEM muffler.
2. Loosen the Torca band clamp on the front of the muffler.
3. Remove the nuts and carriage bolts from the mount bracket behind the muffler and slide off of the head pipe. NOTE: It may be necessary to use a penetrating lubricant to loosen the muffler from the head pipe.
4. Remove the OEM band clamp from the front of the muffler and install onto the Loose Cannonmuffler so that the bolt is to the inside and the nut is facing down.
5. Install the muffler by sliding it onto the head pipe and bolting it to the mount bracket using the OEM nuts and carriage bolts.
6. Align muffler and tighten hardware, beginning with the OEM bolts on the mounting bracket followed by the Torca band clamp. Torque spec. is 40-45 Ft./Lbs. NOTE: Visually check alignment while you tighten the hardware. Make sure the muffler is evenly spaced to the heat shield when viewed from the right hand side of the motorcycle. There should be a gap between the front edge of the muffler and the back edge of the heat shield.
7. Tighten the heat shield.
8. Tighten all hardware before starting your motorcycle.
9. Now go and ride, NO EXCUSES!

### IMPORTANT, PLEASE READ!

We highly recommend the use of thread locking compound on all hardware during installation.

After installation and before starting your motorcycle, completely clean mufflers with warm soapy water and a clean soft cloth. Dry with a clean towel. NOTE: any residue, oil, or fingerprints will stain the black ceramic coating. Do NOT use anything abrasive to clean the pipes as it may remove the finish.

### DISCLAIMER

Firebrand exhaust systems are warranted against defects in material and workmanship for a period of 1 year from the date of purchase from an authorized dealer. This warranty does not cover discoloration or rust of chrome finishes. This warranty is limited to the repair or replacement of a product proven to be defective from normal use. Firebrand exhaust systems are designed to fit and operate on OEM motor and chassis. This warranty does not cover any product subject to abuse, misuse, improper installation or modification. Every effort is made for Firebrand Exhaust Systems to provide improved cornering clearance. However, due to design and space limitations on some motorcycle models, ground and cornering clearance may not be improved and in some cases may be reduced. Be sure to follow proper installation instructions. Aftermarket products that remove OEM pollution control components are not permitted for street use in California. Please check with your local Municipality or visit the CARB website at [www.arb.ca.gov](http://www.arb.ca.gov).

### TOOLS REQUIRED

- 13mm COMBINATION WRENCH
- RATCHET & 15mm DEEP
- SOCKET
- FLAT BLADE SCREWDRIVER

**firebrand**<sup>TM</sup>  
ANYTHING BUT NEUTRAL

