



INSTALL HHI EXTENSION ON PROGRESSIVE MONOTUBE KIT

PLACE MONOTUBE CARTRIDGE IN VICE SNUG BUT NOT TIGHT ENOUGH TO DAMAGE CARTRIDGE. REMOVE MONOTUBE CAP AS SEEN IN THE PHOTOS BELOW. REPLACE STANDARD MONTUBE CAP WITH HHI EXTENSION, APPLY LOCTITE ON HHI EXTENSION BEFORE INSTALLATION AS SHOWN IN PHOTOS BELOW.



LOCTITE
262

THREADLOCKER/FLUIDO DE ROSCAS

HIGH STRENGTH

ALTA RESISTENCIA

26241

WARNING: MAY CAUSE ALLERGIC SKIN REACTION. AVOID CONTACT WITH EYES. WASH THOROUGHLY WITH SOAP AND WATER. See all panel pictures.
NET 3.45 FL. OZ./CONT. NET. 250 ml



LINCOLN





LINCOLN

WD-40
MULTI-USE
PRODUCTS



LINCOLN

LOCTITE
262



LINCOLN

1 1/2" 14MM 15MM 16MM 17MM 18MM 19MM 20MM 21MM 22MM 23MM 24MM 25MM 26MM 27MM 28MM 29MM 30MM 31MM 32MM 33MM 34MM 35MM 36MM 37MM 38MM 39MM 40MM 41MM 42MM 43MM 44MM 45MM 46MM 47MM 48MM 49MM 50MM 51MM 52MM 53MM 54MM 55MM 56MM 57MM 58MM 59MM 60MM 61MM 62MM 63MM 64MM 65MM 66MM 67MM 68MM 69MM 70MM 71MM 72MM 73MM 74MM 75MM 76MM 77MM 78MM 79MM 80MM 81MM 82MM 83MM 84MM 85MM 86MM 87MM 88MM 89MM 90MM 91MM 92MM 93MM 94MM 95MM 96MM 97MM 98MM 99MM 100MM

