



INSTRUCTION SHEET



KLASSIC BARS FOR 2015+ INDIAN SCOUT AND 2016+ SCOUT 60

INCLUDED IN BOX:
Klassik Handlebars
Instruction Sheet

NOTE:
Always refer to model appropriate service manual for procedures and torque specifications

QUESTIONS?
 **EMAIL:** info@getklocked.com
 **CALL:** (605) 996.3700



1. Protect all painted surfaces
2. Remove seat and disconnect negative battery terminal
3. Remove headlamp ring and lens and set aside
4. Label and disconnect handlebar wiring
5. Remove throttle housing and right side grip and set aside
 - a. Do not remove brake line from master cylinder
6. Remove left side grip and switches
 - a. The left side grip is glued on, so take care when removing to avoid damaging the rubber
7. Loosen and remove the 4 fasteners on the speedo/handlebar clamp and remove handlebars
8. Install Klassik handlebars in the handlebar clamp or other suitable fixture for wiring
 - a. It is necessary to lengthen the brake light switch wires and the clutch switch wires 6 inches to allow for internal wiring
 - b. Disassemble handlebar connectors
 - c. Guide wiring through the Klassik handlebars until the controls are properly seated
9. Reinstall connectors, handlebars and check switch operation
10. Clutch cable and brake lines will retain their stock routing
11. Check left and right steering lock to ensure none of the wires or cables will bind
12. Reinstall all removed components using factory torque specifications

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

KLOCK WERKS // GETKLOCKED.COM