



FLARE™ WINDSHIELD OE REPLACEMENT

INCLUDED IN BOX:

(1) OE Replacement Windshield
Instructions

NOTE:

Be careful not to let brackets slide along new Flare™ during install. This can cause a scratch on Flare™ surface.

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Set your stock windshield on a soft scratch-resistant surface.



2. Remove mounting brackets from your stock windshield.

NOTE It helps to start with the side brackets and then remove the top center bracket



3. Clean the brackets of any loose dirt to help prevent scratches on reassembly.

4. Align the top-center bracket and loosely install your brackets onto our Flare™ Windshield.

5. Torque windshield fasteners to factory specifications.



Install bracket hardware using the sequence shown above.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

MORE WAYS TO KLOCK YOURSELF OUT



DEVICE MOUNT POWERED BY IOMOUNT

Klock Werks has designed easy to install, motorcycle model specific mounts that incorporate the iMounts™ system! You simply install the mount to your bike with included hardware, attach the razor-thin iAdapt stainless steel adaptor to your device, and instantly connect to the powerful iCore magnetic carrier. No special case needed!

- // The most universal, secure, and forward compatible device mount on the market!
- // Enjoy rotational adjustments
- // If you upgrade to a new phone or GPS, you don't have to buy a new mounting system.



KLOCK WERKS KLEANING PRODUCTS

We tested many products, and found a company that would combine what we like and remove what we didn't like to create a complete Kleaning product line-up.

- // The recommended cleaner for your Flare™ Windshield
- // Proprietary concoction designed by REAL riders
- // Protects surfaces while repelling dirt
- // Complete line for all finishes
- // Clean, Shine, and protect - just about anything.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192

KLOCK WERKS // GETKLOCKED.COM