



FLARE™ WINDSHIELD FOR INDIAN CHIEFTAIN



EMAIL:
info@getklocked.com



CALL:
(605) 996-3700



1. Raise your windshield all the way up.



2. Remove all 5 mounting screws and square nuts.




TIP: You can place low-tack tape on the back of the square nuts and bracket to help prevent them from falling into the fairing.



4. Install your new Flare™ Windshield and torque fasteners to factory specifications.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

MORE WAYS TO KLOCK YOURSELF OUT



KlipHanger BARS

The ultimate in rider comfort and adjustability, now for your Indian Chieftain and Roadmaster! Find out more online at GETKLOCKED.COM!

DEVICE MOUNT POWERED BY IOMOUNT

Klock Werks has designed easy to install, motorcycle model specific mounts that incorporate the iMounts™ system! You simply install the mount to your bike with included hardware, attach the razor-thin iAdapt stainless steel adaptor to your device, and instantly connect to the powerful iCore magnetic carrier. No special case needed!

- // The most universal, secure, and forward compatible device mount on the market!
- // Enjoy rotational adjustments
- // If you upgrade to a new phone or GPS, you don't have to buy a new mounting system.



KLOCK WERKS KLEANING PRODUCTS

We tested many products, and found a company that would combine what we like and remove what we didn't like to create a complete Kleaning product line-up.

- // The recommended cleaner for your Flare™ Windshield
- // Proprietary concoction designed by REAL riders
- // Protects surfaces while repelling dirt
- // Complete line for all finishes
- // Clean, Shine, and protect - just about anything.