

INSTRUCTION SHEET





UTV FLARE™ WINDSHIELD FOR CAN-AM X3

INCLUDED COMPONENTS:

- (1) UTV Flare™ Windshield (1) Instruction Sheet
(4) Axia Clamp Kits

QUESTIONS?

-  EMAIL: info@getklocked.com
 CALL: (605) 996.3700

INSTALLATION

1. Install the provided rubber trim onto the bottom edge of your Flare™ Windshield
2. Following the provided diagram, install the clamps around the A-pillars and then through the windshield **(1)**
3. Secure the windshield clamps with the thumb screws **(2, 3)**
4. Enjoy your new Flare™ Windshield!

