



Installation Instructions

For Kodlin "New Style" Latch Covers for HD Touring - K59490, K59491

A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

1. Remove the saddle bag and lay it down on a soft cloth so you can get to the tether easily.
2. Remove the two T15 Torx screws for the tether on the lid to expose the three latch cover screws. See picture #1.
3. Remove the three T15 Torx screws holding latch cover on.
4. Carefully replace existing latch cover with the Kodlin USA covers. Insert the three provided small machine screws using a 9/64th allen. Make sure to use medium strength thread locker on the screws and snug down firmly. See picture #2.
5. Replace the two removed T15 Torx screws to secure the tether back in place.
6. Reinstall the saddle bag and repeat for the other side. See picture #3.



#1



#2



#3

NOTE: No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle. We recommend following the Mfg.'s torque specs.

For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 4/3/2024

www.kodlinusa.com