



Installation Instructions

for Kodlin Mini-Trackboard K73244

Note: Must have a Kodlin Splined Peg Adapter installed to use this product

1. Using medium strength thread locker on bolt, install bolt through washer then Mini-Trackboard and then into peg adapter. Align peg as needed then firmly tighten bolt.
2. Check for proper alignment and if not correct, realign. Check again and once properly aligned torque bolt to 15-20 ft/lbs.



For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 5/19/2022

www.kodlinusa.com