



## Installation Instructions

for Kodlin Mini-Trackboard K73255

1. There is thread locker already on bolt, install bolt Mini-Trackboard and then into peg adapter. Align peg as needed then firmly tighten bolt.
2. Check for proper alignment and if not correct, realign. Check again and once properly aligned torque bolt to 15-20 ft/lbs.



#1



#2

For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 3/11/2024

[www.kodlinusa.com](http://www.kodlinusa.com)