



INSTALLATION INSTRUCTIONS

**SISSY BARS for 1980-86 FXWG,
1984-99 FXST, FLST, FLSTF, FLSTN**
Mfg. p/n 263602A, 263608A
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Sissy Bars onto Harley-Davidson® 1980-86 FXWG and 1984-99 FXST, FLST and FLSTF models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

REFERENCE KW P/N

263600	8.75 Lowboy Upright
263601	8.75 Mini Lowboy Upright
263611	8.75 Round Upright
264170	8.75 Ultra Mini Lowboy Upright
264190	8.75 Bantam Upright
264195	8.75 Rail Upright
263602A	Side Straps f/80-86 FXWG and 1984-99 FXST
263608A	Side Straps f/86-99 FLST, FLSTF, FLSTN

TOOLS REQUIRED:

- 2 – 9/16" combination wrenches
- 1 – 5/32" socket wrench

PROCEDURE:

CAUTION: Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the ¼"-20 buttonhead screws to prevent this.

1. Attach sissy bar back to right and left side straps, using hardware provided. Tighten securely.
2. Remove OEM hardware securing fender to fender braces in center two positions on each side. Note sequence of hardware removal for ease of reassembly.
3. Carefully slide complete bar assembly onto outside of fender braces.

NOTE: Apply 1-2 drops of Loctite® 242 (blue) to threads of screws.

1980-86 FXWG: Reuse all OEM hardware.

1984-85 FXST: Use the rear OEM 3/8"-16 x 1 ¼" screws in the front position. Use the provided 3/8"-16 x 1 3/8" screws in the rear position.

1986-99 FXST, FLST, FLSTN: Use the provided 3/8"-16 x 1 3/8" screws in the front and rear positions. On models with saddlebags, use OEM hardware.

1990-99 FLSTF: Use the provided 3/8"-16 x 1 3/8" screws in the front position. The rear position is secured by the OEM turn signal shafts. The sissy bar strap is slotted for convenience in routing the turn signal wires.

4. Align bar assembly and tighten all mounting hardware securely.

WARNING: Before operating motorcycle, check all hardware to be sure it is tight.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

KHROME WERKS®
67 Fifth St. N.E. • Pine Island, MN 55963