# Installation Instructions



# www.motherwellproducts.com ★USA

#### **PICUTRE OF PRODUCT**



#### Attention Installer (if other than owner):

Please forward this instruction sheet to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

#### Welcome:

These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.

**CAUTION**: Start screw carefully to avoid cross threading

WARNING: Never carry more than 10 lbs. on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose and come in contact with moving parts, i.e. wheels, brakes, etc.

## **Tools Required:**

#2 Phillips Screw Driver

#### Parts Included:

Luggage rack

- 2 Foam Tabs
- 1 Nylon Washer
- 1 Stainless Steel Washer
- 1 Phillips ¾" Pan Head Screw

MWL-210 / MWL-210-04 / MWL-216

#### **Fitment:**

Fits Sportster XL Models 85-04. (MWL-210) Fits Sportster XL Models 04-UP. (MWL-210-04/216)

MAX CAPACITY: 10LBS
MATERIAL: 3/8" SOLID STEEL

#### **TECHNICAL SPECS**

PILLION SEAT REPLACEMENT

MAY REQUIRE A MOUNTING KIT - PART NO.

MWL-2000-16

#### **Mounting Procedure:**

- 1) Remove Pillion seat.
- 2) Install foam on the front and back of the rack.
- 3) Place rack on fender mounting points. (The forward mount sits on top of the driver's seat)
- 4) Install the stock screw in to rear pick up point on the rack. (DO NOT TIGHTEN)
- 5) For the front mount, place the nylon washer on the rack with the stainless steel on top.
- 6) From there insert the supplied Phillips screw loosely.
- 7) Proceed to tighten both screws down.

# Use and Care: (For MWL-210/210-04 Only)

Manufacturer's Tip:

We recommend the use of non-abrasive automobile wax to polish our products. This will best maintain the appearance of the product and increase longetivity.

### Use and Care: (For MWL-210/210-04 / MWL-216)

Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemical or cleaners, or high pressure washers.

## THE BEST RIDES START HERE

Motherwell Products USA, Inc 7040 Portal Way #120 Ferndale, WA 98248 Toll Free (877) 703-7118 www.motherwellproducts.com