



## THRASHIN SUPPLY® FLOORBOARD & BRAKE PEDAL INSTALLATION INSTRUCTIONS



### IMPORTANT NOTICE

This installation should be done by an experienced mechanic who has access to a factory service manual and all required tools

### CAUTION

Incorrect installation can cause damage not covered under warranty. Failure to install components correctly CAN result in serious injury to motorcycle, operator, passenger, and/or others.

- 1 Refer to the proper service manual for your model motorcycle and remove the floorboards and brake pedal.
- 2 Wash, clean and inspect all new THRASHIN® parts and hardware
- 3 Clean and inspect any and all bolt holes and mounting surfaces
- 4 When threading in fasteners we recommend always using a dab of lube on the underhead flange of the bolts and using loctite on the threads.
- 5 Install Thrashin Floorboards re using the factory Allen heads, 2 per side – See Fig. 1
- 6 Install rear passenger floorboards re using the factory pins and the supplied set screw – See Fig. 2
- 7 Install brake pedal cover using the supplied ARP bolt See Fig. 3



Fig. 1



Fig. 2



Fig. 3