



THRASHIN[®]

SUPPLY COMPANY

TSC-2904-1 / 3
Softail / Dyna
Adjustable linkage



Step 1: Remove factory linkage.

Step 2: Adjust your new Thrashin linkage to match the length of the stock one by rotating the center shaft and keeping heim joints stationary.

Step 3: Install your new kickass shift linkage on the bike using the supplied 12pt ARP hardware and loctite.

Step 4: Make any necessary adjustments to the linkage to dial in your shifter position.

Step 5: Tighten jam nuts (**NOTE: Left side jam nut is left hand thread, so both nuts will tighten to the same direction**).

Step 6: GO RIDE!

