


## INSTRUCTION SHEET FOR No. 97225-55



## SPROCKET SHAFT BEARING INSTALLATION TOOL

USE ON BIG TWIN 1955-2002 BIG TWINS

See JIMS No. 973 Adapter Tool for 2006 Dyna, 2007 to present Twin Cam with Timken Bearings


## Tools required for use of this tool:

JIMS® No. 94660-37A socket tool or equivalent

H-D® Service Manual using a Timken bearing flywheel lower end. (1955-2002 Big Twin )

## **NOTE:**

- Do not use impact tools on any flywheel assembly. Damage will occur to flywheels, bearings, and tool.
- 2. With the flywheels ready to go into the left case, mount in flywheel rebuilding jig, and clamp in a vice.
- 3. Lubricate the sprocket shaft bearing area with Assembly Lube, and I.D. of bearings.
  - 4. Install the bearing with rollers facing the end of the shaft and spacer. (May need sprocket shaft spacer H-D® No. 24036-70 for first bearing)
- 5. Lube the main body No. 1 I.D. and O.D. of threads. Thread main body onto sprocket shaft with handle No. 4 as far as possible. Then remove No. 4 handle from the No. 1 main body.
- 6. Slip the slider No. 3 over main body No. 1, then install the lubed bearing No. 5 and two washers. Place bearing between the two washers, lubricate.
- 7. Thread hex side of No. 2 nut with shoulder onto the main body No. 1 and tighten until bearing bottoms out on shaft shoulder using JIMS® No. 94660-37A socket tool. See H-D® Service Manual for Timken style bearing torque specifications.
- Remove nut No. 2, slider No. 3, washer and bearings No. 5, and spacer No. 24036-70, and install left case over the sprocket shaft. Do not remove the main body No. 1.
- 9. Slip the Timken inner spacer and bearing with the rollers facing the flywheels onto the sprocket shaft, followed by slider No. 3 and tool bearing and washers No. 5. Thread on nut No. 2 with the hex end facing the flat bearings and washers.
- 10. Tighten No. 2 nut using JIMS® No. 94660-37A socket tool. See H-D® Service Manual for end play and Timken bearing torque specifications.
- 11. See JIMS® No. 39361-69 for installing left case seal with this tool.



PAKIS AVAILABLE SEPAKAIELY			
No	. Qty.	Description	Part No.
1	1	MAIN BODY	97225-55-1
2	1	NUT	1026-B
3	1	SLIDER	97225-55-3
4	1	LONG HANDLE	1028
5	1	BEARING & WASHERS	1047-54

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.