



EXTENDED BRAKE PEDAL, '14-UP TOURING & TRIKE WITH LOWERS, CHROME

9672

Thank You For Choosing Kuryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Extended Brake Pedal
- 1 Cotter Pin

YOU WILL ALSO NEED:

Set of hex wrenches, set of hex bit sockets, set of sockets, set of combination wrenches, grease FT LBS (Nm) torque wrench, and needle nose pliers

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

- STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**. Allow the engine and exhaust system to cool. Remove the main fuse.

WARNING

THE END USER'S SAFETY DEPENDS UPON PROPER INSTALLATION OF THIS PRODUCT. IF A STEP IN THESE INSTRUCTIONS IS NOT WITHIN YOUR CAPABILITIES OR YOU DO NOT HAVE THE CORRECT TOOLS, HAVE YOUR DEALER PERFORM THE PROCEDURE. IMPROPER INSTALLATION OF THIS PRODUCT COULD RESULT IN DEATH OR SERIOUS INJURY.

ACCIDENTAL VEHICLE START-UP COULD CAUSE DEATH OR SERIOUS INJURY, REMOVE THE MAIN FUSE BEFORE PROCEEDING.

INSTALLATION MAY REQUIRE CONTACT WITH THE ENGINE AND EXHAUST SYSTEM; ENSURE THAT IT HAS FULLY COOLED BEFORE BEGINNING TO PREVENT INJURY.

BEFORE RIDING, ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE.

- STEP 2 Remove the brake-side (right) floorboard; loosen the front floorboard mount and rotate it until it is pointing toward the ground.

- STEP 3 Remove the lower engine guard screw from both sides; loosen the top screw; allow the bar/lower assembly to "swing" forward; save the two screws for reinstallation.

- STEP 4 Remove the two screws securing the brake master cylinder assembly to the motorcycle; set the screws aside for now, they will be reinstalled.

- STEP 5 Carefully move the master cylinder forward; do not move the assembly too far forward or damage will occur.

- STEP 6 Remove the nut, washer and O-ring from the existing brake pedal; save the nut and washer for later.

- STEP 7 Refer to PIC 1. Carefully slide the brake pedal and master cylinder assembly outward to gain access to the cotter pin on the backside of the pedal.





- STEP 8 Remove the cotter pin, washer and pivot pin from the pedal; save the pivot pin and washer for later.
- STEP 9 Rotate the brake pedal forward and slide it off the pivot shaft.
- STEP 10 Clean and re-grease the pivot shaft.
- STEP 11 Slide the Extended Brake Pedal onto the shaft; secure it with the existing pivot pin, washer, and included Cotter Pin; bend the ends of the Cotter Pin.
- STEP 12 Secure the Pedal to the pivot shaft with the existing nut and washer; torque to 15-20 FT LBS (20.3-27.1 Nm).
- STEP 13 Secure the master cylinder to the motorcycle with the existing screws; torque to 10.5-12.5 FT LBS (14.2-17 Nm).
- STEP 14 Secure the engine guard to the motorcycle with the existing screws; torque the top screw to 22-28 FT LBS (29.8-37.9 Nm); torque the two lower screws to 15-20 FT LBS (20.3-27.1 Nm).

Reinstall the floorboard and main fuse.

NOTICE

It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials & workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

1. Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
2. The product must be properly installed, maintained & operated under normal conditions.
3. Kuryakyn shall not be liable for any consequential & incidental damages, including labor & paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn & a customer.
4. Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
5. Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'s contained in components of Kuryakyn products will be warranted for defects in materials & workmanship for 3 years from the date of purchase whereas all other components shall be warranted for one (1) year.
6. Merchandise purchased directly from Internet auction sites or any other third party seller is considered sold as is & shall not carry a Kuryakyn warranty. All warranty claims must be directed to the original seller. If unsure please contact the seller to verify they are an authorized Kuryakyn retailer.

RETURN POLICY

Merchandise determined to be defective may be returned up to one year from the date of purchase. Returns must be processed through original seller. Returned merchandise for any other reason other than warranty claims must be in like new condition & subject to a 20% restocking fee. All returns are subject to inspection for determination of full or partial credit. Any returned part that shows evidence of being used or installed contrary to manufacturer's instructions, &/or subjected to improper handling, packaging or return shipping by the customer, will not be eligible for exchange, refund or warranty consideration. All returned electrical items will be inspected & tested. If electrical item is deemed functional, no credit will be issued & item will be returned. All sales are final on discontinued or closeout merchandise.