- Install the smaller exhaust plate to the muffler using [illegible] 5/16-1 8 x 5/8” flat head bolt[illegible] provided in the kit. Use Red Loctite on these two bolts and torque to 20 ft lbs.
- E K d W (} Œ E Œ Œ } Á d] Œ ‰ %
  í r í l î — Z Z } o š • o } v

- Slide the Trask muffler into the head pipe receiver. Push the muffler forward until the two fastener holes on the smaller plate align with the two holes on the larger plate. Connect the two plates using two 5/16-18 x 1-3/4” carriage bolts, two 5/16 flat washers, and two 5/16 pinch nuts. The carriage bolts should enter thru the backside of the larger plate mounted to the frame. Torque to 20 ft lbs.
- Re install the factory passenger peg to remaining threaded hole on the Trask larger frame plate.

- Finish tightening the four head pipe flange nuts at this time. Tighten in alternating pattern to drawn pipe down evenly.
- Tune and enjoy.