

26" Front Fender Spacer Lift Kit Instructions

1. Jack the bike up & remove the front wheel as per the workshop manual.
2. Remove the front fender & place it onto a soft towel. Be careful not to damage the fender whilst installing the brackets.
3. Attach fender spacer kit as below.
 - A. To fit the fender spacer to the inside of the fender, bolt 1 x 5/16" bolt with 2 x flat washers & 1 x nyloc nut, to the top fender mounting hole loosely. (1 washer under the head of the bolt, the other under the nyloc nut).
 - B. Align the bracket to the fender by inserting another bolt into the center hole. Tighten upper nyloc nut to 16-21 ft lbs. Then remove the center alignment bolt.
 - C. Repeat steps A & B for the other side.
4. Refit the front fender and now mounted fender spacers to the bike with 4 x 5/16" bolt & 4 x flat washers. Apply blue Loctite to threads and tighten to 16-21 ft lbs.
5. Check all the clearances. If fork tube covers or sleeves are fitted, ensure proper clearances with fender, covers and triple tree.
6. Fit the front wheel as per the workshop manual.
7. Test ride & recheck all clearances.

Parts Included-

2 x Fender Spacer Brackets

6 x UNC 5/16" Stainless steel bolts

8 x Stainless steel flat washers

2 x Stainless steel nyloc nuts

If you have any questions, feel free to ring us on 07 3252 5381

www.rolliesspeedshop.com