



ROAD BLADES®

Parts Included:

- | | | | |
|---|-------------------------|---|-----------------------|
| 1 | Right Road Blade | 2 | Wire retainers |
| 1 | Left Road Blade | 2 | Y Connectors |
| 4 | Cable ties | | |


Installation Instructions:

1. Remove windshield screws (circled below) and remove windshield. (Fig. 1)
2. Lift the front edge of plastic vent to disengage plastic clips and remove. (Fig. 1)



Mark Center

3. Mark the center of your fairing with tape or dry erase to reference later when installing the LEDs.
5. Using your finger or a plastic pry tool, remove the speaker grills by disengaging the plastic clips (Fig. 2)
6. Remove the T30 torx bolt on both sides of the fairing located by the speaker. (Fig. 3)



7. Remove the two T25 torx bolts on each side of the fairing that hold the wind deflectors. (Fig. 4)
8. Unplug the signal wiring harness on each side of the fairing. (located at the upper right and left) (Fig. 5)
9. Remove the allen bolts on each side of the fairing at the base of the turn signals. (Fig. 6)

(WARNING- YOUR OUTER FAIRING IS NOW DETACHED AND WILL FALL ON THE GROUND IF NOT SUPPORTED)



WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Giro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:

Giro products are designed and manufactured under very strict quality control. Giro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure.


Giro will have no obligation if the customer cannot show proof of purchase.

Warranty will not be granted unless the part is properly installed and maintained.

Giro will not be liable for any consequential and incidental damages, including labor, or non-Giro products.

Please visit our website Ciro3d.com for our complete warranty policy.

10. Remove your outer fairing and set it on a work surface that will not scratch the edges.
11. Determine left and right sides of the LED strip by reading the markings on the strip. This is **important** because the LEDs are directional.
12. Test fit the LED strips to get a feel for where they will sit on the fairing. There should be a small 1/8" gap in the center where you marked. From there, line up the rear edge of the LED strip with the rear edge of your fairing, and follow it around until you reach the end of the strip. Try to keep the strip as flat as possible.



13. Clean the surface with an ammonia based glass cleaner to remove any wax or contaminants.

14. Peel the adhesive backing starting at the wire end, and begin sticking the LED strip to your fairing as described in step 12. It may help to only peel the backing a few inches more than you have installed to keep the rest of the strip from accidentally sticking.

LED strip end point

15. Once you have successfully applied the strips to your fairing, stick the two wire retainers to your inner fairing at the locations illustrated by the two green circles in Fig. 7. Zip tie your wires here.
16. Plug your Y-Harnesses in to the turn signal connectors at the left and right side of the inner fairing. (See Fig. 8) Test to make sure that you have white running light as well as amber turn signal function. Additional zip ties can be used to help neatly route wiring, while leaving enough slack to remove outer fairing.
17. Re-assemble your fairing by repeating steps 1-9 in reverse. Be sure not to pinch the Road Blades® wires when re-installing the outer fairing.

