

Parts Included In CV4652/B:

1ea-CV4652 Bracket

1ea-CV4621/B Curved L/P Frame W/ License Plate Light

1ea - Wire harness Adaptor

Fitment:

- 09 20 Iron 883
- 10 20 Forty Eight
- 12 16 Seventy Two

Curved L/P Relocation

W/ LED's (Sportster)

■ 10 – 12 Nightster

- 1. Must be installed by a Qualified Technician
- 2. Remove rear bolt holding seat, Remove seat and Reinstall seat bolt to hold inner bracket in place.
- 3. Place bike on motorcycle jack or stand, Remove upper shock bolts and allow rear tire and swing arm to hang see Fig 1
- 4. Remove the four bolts and two inner turn signal nuts and remove outer fender strut cover and turn signals see Fig 2.
- 5. Remove stock license plate holder and unplug light from under the seat.
- 6. Install the CV4652 bracket on the inside of inner support bracket.
- 7. Install turn signals cover plates using supplied hardware. See Fig 3.
- 8. Reinstall rear most strut bolts using stock bolts and supplied 5/16-18 flange nuts
- 9. Note: on bikes equipped with sissy bar side plates, it may be necessary to use longer 5/16-18 strut bolts (not supplied)
- 10. Remove nuts from the License plate cover and two of the set screws.
- 11. Remove the License Plate frame from the bracket.
- 12. Notch the License Plate to clear the wire harness as shown in Fig 4.
- 13. Reinstall the License Plate frame.
- 14. NOTE: USE ALLEN WRENCH TO HOLD SETSCREW WHILE TIGHTENING LOCK NUT
- 15. Do not over tighten setscrews.
- 16. Use locktite when installing screws.
- 17. We will not warranty the license plate frame if the setscrew goes through face of the frame.
- 18. Route the wire harness thru the wire loom along the left side of the fender and thru the hole in the fender.
- 19. Plug in using supplied wire harness adaptor.
- 20. NOTE: Will not plug and play on some 13 & older models, in this case it is necessary to cut the 8-pin connector from the frame and hardwire using chart below.
- 21. Check for proper operation.
- 22. Re-install seat.

Wire as follows:

Blue wire to run light circuit.

Black wire to ground.

Red Wire to brake light circuit

Connect the two purple wires to corresponding turn signal circuit.

Our Warranty Policy

Cycle Visions' obligation under "Our Warranty Policy" is limited to one (1) year from date of purchase to repair or replacement of the defective item (s). Chrome, polished, powder-coated, anodized finishes, or electrical parts are limited to thirty (30) day from date of purchase.

This warranty will be void on all products that show evidence of misapplication, improper installation, abuse, lack of proper maintenance, negligence, or alteration from their original design.

The consumer will be responsible for removing from the vehicle any defective item (s), transportation costs prepaid and for reinstallation upon return by Cycle Visions. The loss of use of the product, loss of time, inconvenience, commercial loss or consequential damages is not covered. Cycle Visions reserves the right to change the design of any product without assuming any obligation to modify any product previously manufactured. Warranty returns of Cycle Visions products are few because of our high quality products.

Carefully inspect all parts.... If you find that your parts arrived in damaged conditional all original packaging material (box and other materials) must be saved to make a proper damage claim within seven (7) days. You must be able to present the damaged boxes and materials to the freight carrier to verify your claim. The user shall assume all legal, personal, injury risk and liability and all other obligations, duties and risks associated therewith.

Cycle Visions...

San Diego, CA (619) 295-7800 See our other products on the web!

www.cyclevisions.com







Fig 2





Fig 4 Fig 3

