

Anti-Rattle Spring Installation on PM 6 Piston Calipers

Anti-Rattle Spring Install:

6 Piston PM Calipers can be retrofitted with an anti-rattle spring to reduce pad rattle and noise. This does not effect the performance of the brakes. Installation is relatively simple. PM recommends using this opportunity to inspect and replace your brake pads if necessary.



Remove Cotter pin from brake pad retaining pin.



Slide pin out of outer pad and leave flush with inner pad.



Insert anti-rattle spring with forked side facing down.



Apply pressure to pre-load spring and slide pin back through pads, trapping spring under pin.



Install new Cotter pin.