



2017-18 M8 TOURING 2018 + M8 SOFTAIL MOTO INTAKE

stainless steel Part # 034-464-03



BILL OF MATERIALS

1	M8 Touring Intake Gasket	017C-230
3	1/4 x 20 x 3/4 SS Cap Screw	017C-226
1	TBR Foam Filter w/ Clamp	018-SP-FOAM
1	HD M8 Moto intake Body	034-464B
1	1/4" T-Barb Black	017C-235
1.5	1/4 x 7/16 Tube	017C-236
2	8mm Spacer w/ 10mm ID Clearance	005-S-810
2	7/16 Black Hose Clip	005-HC716

INSTALLATION INSTRUCTIONS

1. Make sure the motorcycle is completely cool before installation. Make sure the motorcycle is secure on a stand or service lift.
2. Remove OEM air filter and housing. **(Reference image 1)**
3. Install intake body using supplied gasket and cap screws. **(Reference image 2)**



Image 1




Image 2

4. Remove and reinstall both OEM breather bolts using supplied 8mm spacers. **(Reference image 3)**
5. Attach black hose clips to ends of breather tubes. **(Reference image 4)**
6. Install the supplied tubing to the T-Fitting using the shortest tube on the bottom of T-Fitting. **(Reference image 5)**




Image 3



Image 4

7. Install the T-Fitting and hoses to the bottom of the intake body and OEM breather bolts and secure hoses using supplied hose clips.




Image 5



Image 6

8. Double check your work to make sure everything is secure and tighten down with no kinks in air lines **(Reference image 6)**
9. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

IMPORTANT - PLEASE READ CAREFULLY: We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a center stand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

WARRANTY: Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve.

TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



BILL OF MATERIALS

1	M8 Touring Intake Gasket	017C-230
3	1/4 x 20 x 3/4 SS Cap Screw	017C-226
1	TBR Foam Filter w/ Clamp	018-SP-FOAM
1	HD M8 Moto intake Body	034-464B
1	1/4" T-Barb Black	017C-235
1.5	1/4 x 7/16 Tube	017C-236
2	8mm Spacer w/ 10mm ID Clearance	005-S-810
2	7/16 Black Hose Clip	005-HC716